



TOWERS TANKS

Pty Ltd

FREE CALL

1800 65 99 46

- Water • Molasses
- Chemical Tanks
- Roller Lickers & Troughs

TANK TIPS

Site preparation:

Always have your base larger than your tank diameter, at least 100mm (4 in.) all round. A level and flat concrete slab is the preferred base for your new tank, however it is not always possible. So alternatively you will need to construct from other materials such as a compacted base using available fill. The base material (fill) should be sand or granular material free from rocks or sharp protrusions, level, flat and compact are the base requirements. The tank base needs a surround to prevent loss of fill and vermin undermining the tank. Once your tank is in position connect the outlet to the water line using a flexible hose. Polypipe is not considered a flexible connection. The overflow also needs to be considered, it should be carried to ground level and kept vermin proof.

Been 'round for years